

# Thermal Actuator

## Introduction

---

For a description of this model, see [Thermal Actuator — Parameterized](#), which describes a version of the same model (called `thermal_actuator_tem_parameterized`) that only differs in the way the geometry is created; while the modeling instructions below describe how you can import the finished geometry from an MPHBIN-file, the instructions in the above referenced model detail the steps required to create the geometry in the COMSOL Desktop.

## Reference

---

1. D.M. Burns and V.M. Bright, “Design and performance of a double hot arm polysilicon thermal actuator,” *Proc. SPIE 3224, Micromachined Devices and Components III*, 1997; doi: [10.1117/12.284528](#).

---

**Application Library path:** MEMS\_Module/Actuators/thermal\_actuator\_tem


---

## Modeling Instructions




---

From the **File** menu, choose **New**.

### NEW

In the **New** window, click  **Model Wizard**.

### MODEL WIZARD

- 1 In the **Model Wizard** window, click  **3D**.
- 2 In the **Select Physics** tree, select **Structural Mechanics>Thermal–Structure Interaction>Joule Heating and Thermal Expansion**.
- 3 Click **Add**.
- 4 Click  **Study**.
- 5 In the **Select Study** tree, select **General Studies>Stationary**.
- 6 Click  **Done**.

### THERMAL ACTUATOR

- 1 In the **Model Builder** window, right-click **Component 1 (comp1)** and choose **Rename**.

- 2 In the **Rename Component** dialog box, type Thermal Actuator in the **New label** text field.
- 3 Click **OK**.

## GLOBAL DEFINITIONS

### Parameters I

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters I**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 In the table, enter the following settings:

Name	Expression	Value	Description
htc_s	$0.04 [W / (m \cdot K)] / 2 [um]$	20000 W/(m <sup>2</sup> ·K)	Heat transfer coefficient
htc_us	$0.04 [W / (m \cdot K)] / 100 [um]$	400 W/(m <sup>2</sup> ·K)	Heat transfer coefficient, upper surface
DV	5[V]	5 V	Applied voltage


## GEOMETRY I

### Import I (impl)



- 1 In the **Home** toolbar, click  **Import**.
- 2 In the **Settings** window for **Import**, locate the **Import** section.
- 3 Click  **Browse**.
- 4 Browse to the model's Application Libraries folder and double-click the file thermal\_actuator.mphbin.
- 5 Click  **Build All Objects**.
- 6 Click the  **Go to Default View** button in the **Graphics** toolbar.

## DEFINITIONS

### substrate contact

- 1 In the **Definitions** toolbar, click  **Explicit**.
- 2 In the **Settings** window for **Explicit**, locate the **Input Entities** section.
- 3 From the **Geometric entity level** list, choose **Boundary**.
- 4 Select Boundaries 10, 30, 50, 70, 76, and 82 only.
- 5 In the **Label** text field, type substrate contact.

**ADD MATERIAL**

- 1 In the **Home** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **MEMS>Semiconductors>Si - Polycrystalline silicon**.
- 4 Click **Add to Component** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Material** to close the **Add Material** window.

**MATERIALS**

*Si - Polycrystalline silicon (mat1)*

By default, the first material you add applies on all domains so you can keep the **Geometric Entity Selection** settings.

- 1 In the **Settings** window for **Material**, locate the **Material Contents** section.
- 2 In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Electrical conductivity	sigma_iso ; sigma <sub>ii</sub> = sigma_iso, sigma <sub>ij</sub> = 0	5e4	S/m	Basic

**SOLID MECHANICS (SOLID)**

*Fixed Constraint 1*

- 1 In the **Model Builder** window, under **Thermal Actuator (comp1)** right-click **Solid Mechanics (solid)** and choose **Fixed Constraint**.
- 2 Select Boundaries 10, 30, and 50 only.

*Roller 1*

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Roller**.
- 2 Select Boundaries 70, 76, and 82 only.

**HEAT TRANSFER IN SOLIDS (HT)**

In the **Model Builder** window, under **Thermal Actuator (comp1)** click **Heat Transfer in Solids (ht)**.

### Heat Flux 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Heat Flux**.

This boundary condition applies to all boundaries except the top-surface boundary and those in contact with the substrate. A **Temperature** condition on the **substrate contact** boundaries will override this **Heat Flux** condition so you do not explicitly need to exclude those boundaries. In contrast, because the **Heat Flux** boundary condition is additive, you must explicitly exclude the top-surface boundary from the selection.

Implement this selection as follows:

- 2 In the **Settings** window for **Heat Flux**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **All boundaries**.
- 4 In the **Graphics** window, click on the top surface to remove it from the selection.

A convective heat flux is used to model the heat flux through a thin air layer. The heat transfer coefficient,  $h_{tc\_s}$  is defined as the ratio of the air thermal conductivity to the gap thickness.

- 5 Locate the **Heat Flux** section. From the **Flux type** list, choose **Convective heat flux**.
- 6 In the  $h$  text field, type  $h_{tc\_s}$ .


### Heat Flux 2

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Heat Flux**.
- 2 Select Boundary 4 only.

A convective heat flux is used to model the heat flux through a thin air layer. The heat transfer coefficient,  $h_{tc\_us}$  is defined as the ratio of the air thermal conductivity to the gap thickness.

- 3 In the **Settings** window for **Heat Flux**, locate the **Heat Flux** section.
- 4 From the **Flux type** list, choose **Convective heat flux**.
- 5 In the  $h$  text field, type  $h_{tc\_us}$ .

### Temperature 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Temperature**.
- 2 In the **Settings** window for **Temperature**, locate the **Boundary Selection** section.
- 3 From the **Selection** list, choose **substrate contact**.

## ELECTRIC CURRENTS (EC)


In the **Model Builder** window, under **Thermal Actuator (comp1)** click **Electric Currents (ec)**.

### Ground 1

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Ground**.

- 2 Select Boundary 10 only.

#### *Electric Potential I*

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Electric Potential**.
- 2 Select Boundary 30 only.
- 3 In the **Settings** window for **Electric Potential**, locate the **Electric Potential** section.
- 4 In the  $V_0$  text field, type DV.

### **MESH I**

#### *Free Tetrahedral I*

- In the **Mesh** toolbar, click  **Free Tetrahedral**.

#### *Size*


- 1 In the **Model Builder** window, click **Size**.
- 2 In the **Settings** window for **Size**, locate the **Element Size** section.
- 3 From the **Predefined** list, choose **Fine**.

#### *Size I*

- 1 In the **Model Builder** window, right-click **Free Tetrahedral I** and choose **Size**.
- 2 In the **Settings** window for **Size**, locate the **Element Size** section.
- 3 From the **Predefined** list, choose **Finer**.
- 4 Locate the **Geometric Entity Selection** section. From the **Geometric entity level** list, choose **Boundary**.
- 5 Select Boundaries 86–91 only.
- 6 In the **Model Builder** window, right-click **Mesh I** and choose **Build All**.

### **STUDY I**

#### *Step 1: Stationary*



- 1 In the **Model Builder** window, under **Study I** click **Step 1: Stationary**.
- 2 In the **Settings** window for **Stationary**, locate the **Study Settings** section.
- 3 Select the **Include geometric nonlinearity** check box.
- 4 In the **Home** toolbar, click  **Compute**.

## RESULTS

### *Stress (solid)*

The first default plot show the von Mises stress.

### *Volume I*

- 1 In the **Model Builder** window, expand the **Stress (solid)** node, then click **Volume I**.
- 2 In the **Settings** window for **Volume**, locate the **Expression** section.
- 3 From the **Unit** list, choose **MPa**.
- 4 In the **Stress (solid)** toolbar, click  **Plot**.
- 5 Click the  **Zoom Extents** button in the **Graphics** toolbar.


### *Temperature (ht)*

- 1 Click the  **Go to Default View** button in the **Graphics** toolbar.


The second default plot shows the temperature field.

Create a new plot for displacement.


### *Displacement*

- 1 In the **Home** toolbar, click  **Add Plot Group** and choose **3D Plot Group**.
- 2 In the **Settings** window for **3D Plot Group**, type Displacement in the **Label** text field.

### *Surface I*

- 1 Right-click **Displacement** and choose **Surface**.
- 2 In the **Settings** window for **Surface**, locate the **Expression** section.
- 3 From the **Unit** list, choose **μm**.
- 4 Locate the **Coloring and Style** section. Click  **Change Color Table**.
- 5 In the **Color Table** dialog box, select **Rainbow>SpectrumLight** in the tree.
- 6 Click **OK**.

### *Deformation I*

- 1 Right-click **Surface I** and choose **Deformation**.
- 2 In the **Displacement** toolbar, click  **Plot**.

